











FLEX-display™ Assembly # B3

- 1 x CROSS BASE
- 1 x Telescopic pole
- 1 x FLEX-Clip
- 1 x Grip-Clip
- 2 x Horizontal bar
- 1 x Banner



FLEX-display™ Assembly # H3

- 1 x TWIN BASE
- 2 x Telescopic pole
- 2 x FLEX-Clip, top
- 2 x Grip-Clip
- 2 x Horizontal bar
- 1 x Banner

